

Instructions



When the smoke alarms sound

If there is a fire, immediately evacuate the premises and telephone 000.



Locate the source smoke alarm(s)

If the FIRE indicator is lighting and there is no obvious fire, the user may trace the source alarm using the Locate button.

1. Press the LOCATE button 1 time. The red LED on the Controller will change from flashing to steady glowing.
2. After 3 seconds, all other interconnected smoke alarms will stop alarming and flashing except the source smoke alarm.

Note: The Controller will turn off the Locate Mode after 2 minutes. If the user has not yet traced the source alarm, repeat from No 1.



Silence the source alarms

If you are satisfied there is no fire but the smoke alarm is still continuing to alarm, you may now silence the alarm.

1. Press the TEST/SILENCE button 1 time on the Controller. The red LED on the Controller will change from flashing to steady glowing.
2. After 5 seconds, the source smoke alarm will enter silence mode. All other interconnected smoke alarms will then stop sounding. The silence feature has been completed.